

To install a LPR print queue on Windows XP:

1. Click **Start**, and then click **Printers and Faxes**.
2. In the left panel labeled Printer Tasks, click on **Add a printer**.
3. In the Add Printer Wizard, click **Next**.
4. Select **Local Printer Attached to this computer**, and then click **Next**.
5. Click **Create a new port**, and change the Type of port to **Standard TCP/IP Port**, and then click **Next**.
6. Be sure the Lantronix print server is turned on, and then click **Next**.
7. Enter the Lantronix device's **IP address** for the Printer Name or IP Address, and then click **Next**.
8. Click **Custom**, and then click **Settings**.
9. In the Protocol section select **LPR**
10. In the LPR Settings section enter the appropriate service name on the Lantronix Device as the **Queue Name** that you want to print to. [See below for an explanation of services.]
11. Click **OK**
12. Click **Next**
13. Click **Finish**
14. Select the appropriate **Manufacturer** for printer being attached and then select the **Printer** that matches the service you selected above, and then click **Next**.
15. If the driver already exists you will need to select whether you want to **keep or replace** the existing driver, and then click **Next**.
16. You may change the **Printer Name** as needed, select whether the printer is to be used as the **default printer**, and then click **Next**.
17. You need to select whether or not the printer is to be **shared**, and then click **Next**.
18. You need to select whether or not to **print a test page**, and then click **Next**.
19. Click **Finish**.

How to Examine a D-Link Device Services

To obtain the print service name, perform the following steps:

1. telnet to print server
2. input password
3. select 2 - Port Configuration
4. select 1 - Port 1 (USB)
5. copy down the information for 1 - Port Name. This is the name of the service to be used by Windows.
6. select 0 - Return to Port Menu
7. select 0 - Return to Main Menu
8. select 0 - Quit